



## TEXPRINT SUBLIMATION PAPER ON A KOOZIE



1. Set temperature to 400°F
2. Set timer to 30 seconds.
3. Set Pressure at medium.
4. Print a mirror image onto Texprint Paper.
5. Place paper face down on Koozie (Use heat transfer tape to keep design in place if needed).
6. Press at 400°F for 30 seconds with medium pressure.
7. Remove paper immediately and peel hot.